



A9165

MACK REAR CRANKSHAFT SEAL/WEAR SLEEVE INSTALLER



- Applications: MACK E-6 and E-7 / E-7 ETECH
- Works on the following seals: 25500973, 20705740, 20705209, 20705626, 20706534, 25624093, 41035000811075, 41035000823052, 446GC250, 446GC251, 446GC310P10, 446GC310P6, 446GC310P7, 446GC311, 446GC311A, 446GC311B, 446GC312
- NATIONAL SEALS - (F/MOGUL) 39807, 2297, 2297S, 5231
- It must be used when installing seal & wear sleeve together. Note caution when installing Teflon seals, Do not lubricate Teflon seal lips. Oversize inside diameter lip seal and wear ring are shipped assembled, do not remove before assembly. Attach oil seal installation tool plate to the crankshaft using 3 guide pins. Install press cup and driver hex. Tighten the hex nut until positive stop is felt. Check for proper depth. Seals are installed with yellow lip towards transmission.
- OEM no.ref: J-37716-B