



ISUZU NPR 4.8L 5.2L CRANK REAR SEAL WEAR RING INSTALLER TOOL



- This tool is to install the rear crankshaft oil slinger
- Application: Medium Duty Truck, NPR, Isuzu 4.8L 4HE1 and 5.2L 4HK1 diesel engine
- OEM no. ref. J-43282-RR

Step of usage

- 1. Press-fit the slinger using an oil seal installer kit.
- 2. Put the sleeve over the adapter, place a washer on the center bolt and tighten the bolt until the sleeve touches the adapter to press fit the rear slinger.