


IVECO/ FUSO CRANKSHAFT REAR OIL SEAL REMOVEAL TOOL



- Tool to remove crankshaft rear oil seal.
- For oil seal installer please refer to B1676.
- Application: IVECO F1C ENGINE / FUSO LIFT CARS (EURO 5)
- Models: DAILY
- IVECO OEM no.ref.:99340060
- FUSO OEM no.ref.:MH063961

**B1676
FUSO (3.5 TONS) TRUCK
CRANKSHAFT FRONT OIL
SEAL INSTALLER**

